

Bluetooth® Remote Controller

User's Manual

Version 1.0 2013/12

ID NO:

About This Manual

This manual is designed to assist you in installing and using the Bluetooth® Remote Controller. Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice.

Edition

1st Edition,

Copyright

© Copyright 2013

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

Trademarks

All trademarks and registered trademarks are the property of their respective owners.

FEDERAL COMMUNICATIONS COMMISSION STATEMENT

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ◆ Reorient or relocate the receiving antenna.
- ◆ Increase the separation between the equipment and receiver.
- ◆ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions:

1) this device may not cause interference and

2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Caution:

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN
INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE
INSTRUCTIONS.

Introduction

Thank you for purchasing the **Bluetooth® Remote Controller**. This User's Manual contains information that will help to operate the device as well as answering questions about certain special keys and buttons. Please keep this manual in a safe place for future reference.

System Requirements

- iPhone 4/4S/5/5S/6 iPad/ iPad2/ The New iPad/ iPad mini/iPad Air
- Smart phones and tablet PCs with Android 3.0 or higher
- Bluetooth 2.1 or higher

Package includes:

Bluetooth® Remote Controller * 1, Manual * 1





Device pairing







1. Turn on the Bluetooth from iPad/Smart Phone.
2. Turn on the BRC-100 power and press the “CONN” button. (Please make sure the red LED is flashing)
3. The device “Bluetooth Remote controller” displays on iPad/Smart Phone. Then, choose “Connect”.
4. Start to use BRC-100.


Note: 1. Please press any key to re-establish the connection between BRC-100 and iPad/Smart Phone after turning the Power Switch On.

2. There is a power switch at back of the BRC-100. When not in use, please turn to OFF to save battery power.

Key function description:

Function name		Android	ios
	V+ / QuickShot	Increases the device's sound volume. Hold on to increase volume more quickly.	Increases the device's sound volume. Hold on to increase volume more quickly. / QuickShot
	Pre-track	Switches to the previous media track. Press once for each preceding media track.	Switches to the previous media track. Press once for each preceding media track.
	Play/Pause	Switches between Play and Pause. Once Pause is pressed, pressing this button again resumes play.	Switches between Play and Pause. Once Pause is pressed, pressing this button again resumes play.
	Next track	Switches to the next media track. Press once for each subsequent media track.	Switches to the next media track. Press once for each subsequent media track.

-	V-	Decreases the device's sound volume. Hold on to decrease volume more quickly.	Decreases the device's sound volume. Hold on to decrease volume more quickly.
	Home / Siri	Back to main screen.	Back to main screen. / Hold on 1 seconds into the Siri system
	Backspace	Back to previous page	Non-function
	Move up	Move up. Hold on to move up more quickly	Non-function
	Move left	Move left. Hold on to move left more quickly	Non-function
OK 	Enter key / QuickShot	Enter key / QuickShot	Non-function
	Move right	Move right. Hold on to move right more quickly	Non-function

	Move down	Move down. Hold on to move down more quickly	Non-function
---	-----------	---	--------------

Note:

- 1. For MIUI version XXXX under Mii, Enter key will not perform QuickShot in Camera. Please enable V+ for QuickShot under Camera setting and use V+ key on the remote control for quick shooting.**
- 2. Android QuickShot function is only compatible with standard Android photo apps. This function might not work in certain special photo apps, such as the Camera function in Sony Ericsson phones.**

Troubleshooting

- Make sure installed the batteries correctly. Check to make sure the batteries installed are not dead. Try the batteries in another device.**